ESD Testing - Practical tips

Tim Maas ESD Consultant November 4th, 2014

ESD testing – practical tips

- Topics
 - Walking test
 - Floor measurement probes
 - 1 M Ω series resistance in floor connections & wrist straps
 - New NPR ESD specification & test protocol




What IS protected here, actually?


Would "Low ESD Risk Area" not be a better name?

ESD testing – practical tips → Walking test (footwear & vehicles)

Things to keep in mind during a walking test:

- Material combination?
- Surfaces free of contamination?
- Expected result (Ω)?
- Impedance known between electrode and point of floor contact?









ESD testing – practical tips → Walking test (footwear & vehicles)

→ Material combinations


Synthetic rubber + Polycarbonate



Synthetic rubber + Hard anodized Aluminum



Synthetic rubber + foam packaging



Synthetic rubber + POM



ESD testing – practical tips → Floor measurement probes

Things to keep in mind using floor measurement probes:

- Surfaces free of contamination?
- Type of test?
- Usage of cleaning agents?
- Test weight?



Probe acc. to NEN 1081



Probe acc. to IEC61340-4-1

ESD testing – practical tips \rightarrow 1 M Ω series resistance in floors & wrist straps


floor grounding

Things to keep in mind about the commonly installed 1 M Ω series resistance:

- Electrical safety?
- Test voltage?
- Grid wise grounding?







ESD testing – practical tips \rightarrow 1 M Ω series resistance in floors & wrist straps


→ Wrist strap grounding

Things to keep in mind about the commonly installed 1 M Ω series resistance:

- Electrical safety?
- Test voltage?
- When is an EBP with 1 M Ω needed?







ESD testing – practical tips

→ Introduction new NPR ESD specification & Test protocol

NPR: Nederlandse Praktijk Richtlijn

- To provide guidance when ordering and commissioning new ESD floors
- NPR will allow for:
 - plan & planning guidance
 - role definition of parties involved
 - Test method to be applied
 - Independent technical appeal protocol
- → This NPR can also be used for the entire EPA environment ←